

Removal of Microorganisms and Antibiotic Resistance Genes in AWTFs

Scott Miller, PhD and Rose Kantor, PhD

CWEA Water Reuse Workshop
Emerging Issues in Potable Reuse

January 15, 2020



Outline

- Background on antibiotic resistance and removal by advanced treatment
- Our recent findings on removal of bacteria and resistance genes from two AWTPs

Background: Resistance is part of a bacterial arms race



- Bacteria and fungi make antibiotics against each other
- Resistant bacteria are more fit
- Resistance is found in natural environments

Image credit: Alice C. Gray, <https://newsroom.uw.edu/>

Background: Resistance is part of a bacterial arms race




Image credit: Alice C. Gray, <https://newsroom.uw.edu/>

- Bacteria and fungi make antibiotics against each other
- Resistant bacteria are more fit
- Resistance is found in natural environments

Van Goethem et al. *Microbiome* (2018) 6:40
<https://doi.org/10.1186/s40168-018-0424-5>

Microbiome

RESEARCH

Open Access



CrossMark

A reservoir of 'historical' antibiotic resistance genes in remote pristine Antarctic soils

Marc W. Van Goethem^{1†}, Rian Pierneef^{2‡}, Oliver K. I. Bezuidt¹, Yves Van De Peer^{1,3,4,5}, Don A. Cowan¹ and Thulani P. Makhalanyane^{1*}

Background: Resistance is part of a bacterial arms race





Image credit: Alice C. Gray, <https://newsroom.uw.edu/>

- Bacteria and fungi make antibiotics against each other
- Resistant bacteria are more fit
- Resistance is found in natural environments
- Humans are now part of the arms race
- Our battleground is hospitals and clinical settings
- Concern is resistant pathogens, NOT all bacteria

Background: How does antibiotic resistance arise?


Background: How does antibiotic resistance arise?

1) Genetic mutation




Background: How does antibiotic resistance arise?


1) Genetic mutation



2) Horizontal gene transfer




Background: Wastewater as a hotspot for ARGs



- High density of human-associated bacteria
- Lots of opportunity for horizontal gene transfer
- High concentrations of antibiotics that select for resistance

Background: Removal during advanced treatment

ARB = Antibiotic Resistant Bacteria




ARG = Antibiotic Resistance Genes



Background: Removal during advanced treatment

ARB = Antibiotic Resistant Bacteria

Treat these the same as removal of all bacteria







ARG = Antibiotic Resistance Genes

Treat these the same as removal of organic chemical constituents







Background: Removal during advanced treatment processes







Process	WWTP	Ozone	BAC	MF	RO	UV-AOP

Background: Removal during advanced treatment processes







Process	WWTP	Ozone	BAC	MF	RO	UV-AOP
Treatment Mechanism	Biological Physical Removal	Oxidation	Biological Physical Removal	Physical Removal	Physical Removal	Oxidation Irradiation

Background: Removal during advanced treatment processes



Process	WWTP	Ozone	BAC	MF	RO	UV-AOP
Bacteria	+	+		+	+	+
Treatment Mechanism	Biological Physical Removal	Oxidation	Biological Physical Removal	Physical Removal	Physical Removal	Oxidation Irradiation

Background: Removal during advanced treatment processes



Process	WWTP	Ozone	BAC	MF	RO	UV-AOP
Bacteria	+	+		+	+	+
Free DNA	+	+	+		+	+
Treatment Mechanism	Biological Physical Removal	Oxidation	Biological Physical Removal	Physical Removal	Physical Removal	Oxidation Irradiation


Key questions in our research

1. How well does advanced treatment remove bacteria?
2. How well does advanced treatment remove ARGs?
3. Are the SAME bacteria present before and after treatment?


Study sites

Two pilot treatment trains sampled

El
Paso



Two pilot treatment trains sampled




1. How well does advanced treatment remove bacteria?

Quantification of TOTAL cells using flow cytometry

1. How well does advanced treatment remove bacteria?

Quantification of TOTAL cells using flow cytometry

1. Grab sample




2. Stain all cells with DNA-binding green fluorescent dye

3. Pump known volume of sample through instrument

1. How well does advanced treatment remove bacteria?


Quantification of TOTAL cells using flow cytometry

1. Grab sample



2. Stain all cells with DNA-binding green fluorescent dye

3. Pump known volume of sample through instrument



1. How well does advanced treatment remove bacteria?

Quantification of INTACT cells using flow cytometry


An intact cell membrane is an indicator of potential viability

1. How well does advanced treatment remove bacteria?

Quantification of INTACT cells using flow cytometry

An intact cell membrane is an indicator of potential viability

1. Grab sample



- 2a. Stain all cells with DNA-binding green fluorescent dye


- 2b. Stain cells with broken membranes with DNA-binding red fluorescent dye

3. Pump known volume of sample through instrument

El
Paso




Site
A




El Paso



Site A



1. Treatment removes nearly all bacteria but there is growth after treatment




2. How well does advanced treatment remove ARGs?

Quantification of ARGs using qPCR

2. How well does advanced treatment remove ARGs?


Quantification of ARGs using qPCR

Repeatedly copy DNA



2. How well does advanced treatment remove ARGs?


Quantification of ARGs using qPCR



Repeatedly copy DNA


2. How well does advanced treatment remove ARGs?

Quantification of ARGs using qPCR




1. During copying, use a fluorescent dye to quantify how much DNA is present.
2. Measure fluorescence after each cycle of copying.
3. Count how many cycles it takes to reach a threshold fluorescence value.
4. Use known standards to calculate gene copies per mL of sample

2. How well does advanced treatment remove ARGs? (Site A)



2. How well does advanced treatment remove ARGs? (Site A)




3. Are the SAME bacteria present before and after treatment?


Inventorying bacteria with DNA sequencing

3. Are the SAME bacteria present before and after treatment?


Inventorying bacteria with DNA sequencing




3. Are the SAME bacteria present before and after treatment?




3. Are the SAME bacteria present before and after treatment?



3. Are the SAME bacteria present before and after treatment?





Kantor et al. 2019



Kantor et al. unpublished

Summary

- Rise of antibiotic resistance (arms race)
 - ARGs are present at background levels in pristine environments
 - We are most concerned when they are in pathogens
- Wastewater is a “hotspot” for ARGs
- Methods: flow cytometry, qPCR, DNA sequencing
- Removal of bacteria and DNA through treatment:
 - How well does treatment remove bacteria? **Very well.**
 - How well does treatment remove ARGs? **Very well.**
 - Are the SAME bacteria present before and after treatment? **No/not many.**
- Concluding thought: drinking water distribution is not sterile



Acknowledgements

Funding

NSF ERC “ReNUWIt”

EPA STAR

EPWater

Utility Partners

--*City of El Paso*--

Fernie Rico

Gilbert Trejo

Elizabeth DeMoultrie

Academic Partners

--*UC Berkeley*--

Prof. Kara Nelson (supervisor)

Lauren Kennedy

Hannah Greenwald

--*UT Health*--

Prof. Roberto Rodriguez

Cesar Navar

Industry Partners

--*Arcadis U.S.*--

Priscilla Sandoval

--*Carollo*--

Dr. Caroline Russell


Corin Marron

Questions?



Appendix

ARGs through Orange County GWRS



ARGs through Orange County GWRS

